



- 800 Enter HRV Test Mode — 802
- Enter User's Personal Physical Information — 804
- Program HRV Beats Per Minute Threshold — 806
- Continuously Monitor Heart Rate — 812
- HRV Beats Per Minute Threshold Exceeded — 814
- Initiate Heart Beat Recorder and HRV Test — 815
- Conclude HRV Test and Heart Beat Recorded Stopped — 816
- Process Data
- Display, Store and/or Transfer HRV Test Results

FIG 19